



RUST BUSTER

RB7820
ABS Crossmember
2001-2010 Chevy/GMC 2500HD
Standard Cab – 8ft. Bed



REQUIRED TOOLS

Jack Stands or Lift
Paint/Primer
Hand Grinder
Cutting Wheel or Torch
Welding Gloves
Welding Hood/Shield
Ear & Eye Protection
Sockets & Wrench
Fire Extinguisher
Hammer

KIT CONTAINS

ABS Crossmember
M10 Flanged Hex Screw
M10 Flange Locknut

QTY

1
8
8



RUST BUSTER

RB7820
ABS Crossmember
2001-2010 Chevy/GMC 2500HD
Standard Cab – 8ft. Bed

1) PREPARING YOUR VEHICLE

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

Keep all flammable materials away from the vehicle work area.

2) PREPARING YOUR WORKSTATION

Keep a fire extinguisher close by in the case of fire and make sure you always have a designated “Fire Watch” to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



WARNING!

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



RUST BUSTER

RB7820 ABS Crossmember 2001-2010 Chevy/GMC 2500HD Standard Cab – 8ft. Bed

3) PREPARING FOR YOUR INSTALL

Lift up your vehicle. Remove any lines or power harnesses in the work area.

4) CUT

Cut out the rivets retaining the factory ABS crossmember and remove your crossmember.



5) INSTALL

Hold your replacement ABS crossmember up to the underside of your frame rail using the frame holes to help with the alignment. Then screw in the included hardware.



After screwing in your hardware, tighten them with a 14mm socket and 15mm wrench.





RUST BUSTER

RB7820
ABS Crossmember
2001-2010 Chevy/GMC 2500HD
Standard Cab – 8ft. Bed

6) PAINT

Paint the part with primer or other rust inhibitor to help prevent or reduce the risk of rust formation

We recommend our Rust Buster Rust Converter & Primer Spray Paint (RB9917).

